



- INSTALLATION SEQUENCE:
1. PLACE GEOGRID ON LEVEL BACKFILL.
  2. EXTEND GEOGRID TO FRONT FACE OF UNIT
  3. INSERT PAC CLIP
  4. PLACE NEXT UNIT
  5. PULL GRID TAUGHT AND SECURE
  6. PLACE AND COMPACT BACKFILL

# GRID & BLOCK CONNECTION